Figure 3: ST11M/ST11R ST412 Interface Controller



Jumper Setting at W1	BIOS Address	Port Address
No Jumpers Installed	**C8000H (Default)**	320H - 323H
Pins A-B Shorted	D0000H	324H - 327H
Pins C-D Shorted	D8000H	328H - 32BH
Pins A-B and C-D Shorted	E0000H **(Do not use on AT-class system)**	32CH - 32FH